

PART NUMBER: 0000-8K-H10

CARGO NET

APPLICABLE MODELS: 2011> MAZDA 6

PACKAGE CONTENTS

Cargo Net Installation Instructions

Hardware Kit (Part Number: 0000-8K-L32)



Anchor Assy



T-Anchor Plastic Retention Clip Weld Stud

TOOLS REQUIRED

Small flat-tip screwdriver

1

Remove Trim Plugs

- 1. Open trunk.
- 2. Locate 4 plastic fasteners on trunk sill plate inside trunk, 2 each side.
- 3. Using a small screwdriver, remove the plastic fasteners by prying out the center. (Fig. 1)





Fig. 1


2


Install Hardware

- Pull upper corner of trunk sill plate and fabric liner from trunk wall and insert weld stud through upper hole in the support bracket on each side.
 (Fig. 2A)
- 5. While holding stud in place, snap plastic retention clip over weld stud from front to secure in place, each side. (Fig. 2B)










3

Install Cargo Net

9. Install the cargo net by pulling each corner bungee loop around T-Anchors. (Fig. 6A) Ensure the cargo net opening is in the up position and the pull handle is facing rearward. (Fig 6)






Fig. 6