




PART NUMBER: BLMS-8M-L06 Scuff Pl	APPLICABLE MODELS: 2010 ≥ MAZDASPEED3	
PACKAGE CONTENTS:	TOOLS REQUIRED: 50% ISOPROPYL ALCOHOL/RESIDUE FREE CLEANER FREE CLEANER LINT FREE CLOTH Image: Complete the state of the state	
CAUTION: Failure to install this part correctly could result in damage to the vehicle and/or injury to the customer. Make sure to follow the instructions properly to ensure a good installation. Read entire installation instructions before proceeding.		
 Prepare Vehicle Vehicle and scuff plate should be at 13 degree Celsius – 32 degrees Celsius (55 degrees Fahrenheit – 90 degrees Fahrenheit) for best results. Clean all dirt or other contaminants from surface. Using alcohol and cloth thoroughly clean surface to be adhered to. Allow sill area to completely air-dry. 		
 Prepare Alignment Template: A. Check scale on template for accuracy. (Page 5) B. Cut out templates following outline. (Figure 1) 		
Template Page	Figure 1 6/16/09	

3. Place Template and Mark for Fore Sill Placement:	
 A. Hold template at the front of sill area in location "A". Align template to inner molding edge.(Figure 2) B. Mark sill placement per template with wax pencil. (Figure 3) 	
Template	
	Figure 2
Wax Pencil	
	/ ,
Figure	23
4. Place Template and Mark for Aft Sill Placement:	
A. Hold template at the Rear of sill area in location "A".	
Align template to inner molding edge.(Figure 4) B. Mark sill placement per template with wax pencil. (Figure 5)	
	Figure 4
Template	
Wax Pencil Figure	9 5
5. Place Template and Mark for In-Out Sill Placement:	
 A. Hold template vertical at the front side of sill area. Align template to step edge.(Figure 6) B. Mark sill placement per template with wax pencil. (Figure 7) 	
Template	Figure 6
Wax Pencil	
2 Figure	e 7 6/16/09







6/16/09